

SAMS SOUTHERN HIGHLANDS

Quick Reference Guide - Model NESS 5000

To ARM –

- Check all windows and doors are closed.
 - Press '0' 'END'
- The red ARMED led will come on and the codepad will give 3 beeps. System is On.

To DISARM –

- Enter the premises via the normal entry path.
 - Press a valid code number into the codepad followed by 'END'
- The red Armed led will turn off and the codepad will give 3 beeps. System is Off.

To Isolate zones – To isolate any of the zones, turn the alarm on, press '7' 'END', the 'zone excluded' light will come on number(s) to be isolated then '*', then arm the system by pressing '3' or the valid code number. Press the sector number that you wish to isolated followed by 'END'. Finally press the 'END' to turn the system on.

Eg. To isolate zones 4 and 5. press,
0 END 7 END 4 END 5 END END

Alarm memory

Press **5 END**
The last zone to trigger the alarm will flash

Panic Button -

Press **3 END**, to sound the sirens, to reset just switch the system off

Reset system & smoke detectors:

Press **END**

Change Code Number.

- 'Program' Master Code 'End'
- 'Program' '1' 'End'
- New Code 'End'
- New Code 'End'
- 'Program' 'End'

SAMS SOUTHERN HIGHLANDS

Quick Reference Guide - Model NESS 5000

To ARM –

- Check all windows and doors are closed.
 - Press '0' 'END'
- The red ARMED led will come on and the codepad will give 3 beeps. System is On.

To DISARM –

- Enter the premises via the normal entry path.
 - Press a valid code number into the codepad followed by 'END'
- The red Armed led will turn off and the codepad will give 3 beeps. System is Off.

To Isolate zones – To isolate any of the zones, turn the alarm on, press '7' 'END', the 'zone excluded' light will come on number(s) to be isolated then '*', then arm the system by pressing '3' or the valid code number. Press the sector number that you wish to isolated followed by 'END'. Finally press the 'END' to turn the system on.

Eg. To isolate zones 4 and 5. press,
0 END 7 END 4 END 5 END END

Alarm memory

Press **5 END**
The last zone to trigger the alarm will flash

Panic Button -

Press **3 END**, to sound the sirens, to reset just switch the system off

Reset system & smoke detectors:

Press **END**

Change Code Number.

- 'Program' Master Code 'End'
- 'Program' '1' 'End'
- New Code 'End'
- New Code 'End'
- 'Program' 'End'